

Setup


1 Description of XaviX Tennis Racket.

Package contents of XaviXTENNIS

System Cartridge (1)
Blue Racket (1)
Quick Set-up Guide (1)
Serial No. Label (4)

Red Racket (1)
User's Guide (1)
Registration Card (1)

The Tennis Rackets includes four AA batteries.
Please see the user's guide for replacement instruction.




- ① Infra-Red Transmitter
- ② Racket face
- ③ Grip
- ④ Wrist Strap
- ⑤ Adjuster
- ⑥ Button

Use this button for charging the net or selecting items on the screen. This button also doubles as the ENTER Key.

Insert your hand into the wrist strap. Slide the adjuster towards your hand to tighten. Slide the adjuster away from your hand to loosen.


2 Setup XaviXPORT.



Please be sure that the A/V mini-plug is firmly inserted into the back of the XaviXPORT.

*XaviXPORT typically sold separately unless clearly indicated on the package that the PORT is included.


3 Insert System Cartridge.



INSERT the cartridge into the PORT and slide the cartridge towards the front of the PORT. Press the PORT power switch and check to be sure the green power light is on.

4 Remove the battery insulation tape.

Tennis Rackets




To start using the Tennis Racket, remove the insulation tape.


How to play Tennis

1 Distance and Angle.

Side view



Top view



We recommend the above interactive distance and angle.



Do not point the remote control of a TV, at the XaviXPORT. Doing so might cause it to malfunction.

To ensure the safety of yourself and others, please allow adequate space to accommodate a full swing.

2 Enjoy "XaviX TENNIS".

For further details, refer to the "XaviXPORT User's Guide" "XaviXTENNIS User's Guide".